



MACK INDUSTRIES, INC.
P O Box 335 ~ 201 Columbia Road
Valley City, Ohio 44280
Dedicated Service Line: (866) 483-6225
servicedept@mackconcrete.com

BASIC TROUBLESHOOTING FOR FAILSAFE SYSTEMS:

AERATOR ALARM:

1. OPEN PANEL
2. HIT RESET BUTTON

IF ALARM CONTINUES:

1. TURN SYSTEM OFF
2. UNPLUG AERATOR
3. PULL AERATOR – CLEAN ANY DEBRIS OFF SHAFT
4. CHECK WATER LEVEL – SHOULD NOT HIT FOAM RESTRICTOR ON AERATOR
5. REINSTALL AERATOR
6. PLUG AERATOR IN
7. TURN SYSTEM ON (MAY HAVE TO HIT RESET BUTTON)

PUMP (HIGH LEVEL) ALARM:

1. OPEN PANEL
2. HIT RESET BUTTON

IF ALARM CONTINUES:

1. CHECK FLOAT (MAKE SURE NOT HUNG UP ON SIDE OF TANK)
2. IF FLOAT LOOKS GOOD – TRY UNPLUGGING FLOAT & PLUGGING PUMP IN DIRECT (IF PUMP COMES ON THE FLOAT NEEDS TO BE REPLACED) – CALL MACK SERVICE
3. TRY BYPASSING THE AERATOR – RUN EXT CORD DIRECTLY TO PUMP (IF PUMP COMES ON THERE IS A PROBLEM WITH THE AERATOR) – CALL MACK SERVICE

IF ALARM CONTINUES AFTER TROUBLESHOOTING:

1. HIT SILENCE BUTTON ON SIDE OF PANEL
2. CALL MACK SERVICE